

## **M**DESIGN

## 25W SHOULDER TYPE MEGAPHONE




## **OPERATING INSTRUCTIONS:**

(1) UNCLIP LATCH TO ACCESS BATTERY COMPARTMENT.



(2) INSERT 8 x AM2 C SIZE BATTERIES
(NOTING BATTERY POLARITY IN HOLDER).
REPLACE COVER AND RE-CLIP LATCH.



(3) MOVE SWITCH LEFT FOR AUTO SIREN/RIGHT TO TALK.

(4) ADJUST VOLUME AND LOCK/PRESS SWITCH TO TALK.

